

Surface Preparation

Fact Sheet for self adhesive vinyl



To help make your SAV installation process easier and ensure the best result, Flash Photobition has the issued below guidelines. Please keep in mind that the better the wall finish the better the end result.

New Walls

To ensure a maximum bond with any self adhesive product there are some pitfalls to watch out for.

Many modern paints now have repelling characteristics like Wash and Wear, Teflon, Silicon or latex added. These properties affect the adherence of a SAV to the painted surface.

It is very important that the painting contractor is aware of this, as choosing the wrong paint can potentially ruin a project. It has become increasingly hard to find paint that does not have these characteristics.

If in doubt, Flash Photobition recommends using **Dulux**

Aquanamel Gloss. If the painter uses a paint other than the paint specified, Flash Photobition is not in a position to warrant the install due to a high risk of adhesive failure.

Two (2) coats of paint are recommended with a fine nip roller as a large nip roller will leave a textured effect that will be visible through the graphics. A textured paint surface will also reduce the contact surface between adhesive and wall and therefor reducing its ability to bond. With the adhesive only adhering to the peaks of the paint it will reduce the contact surface to ONLY 20-30% compared to 100% on a correctly

prepared smooth wall. The walls will also need to be wiped down before the 1st coat is applied to remove all dust from sanding. After the first coat a light sanding is recommended to remove any small paint heads that may exist. This will allow for a high quality finish. The paint needs to have adequate drying time (out gassing) prior to install to avoid bubbling. A minimum of 48 hours drying time is recommended after the last coat has been applied. If these recommendations are followed you will have a great looking end result. If these instructions do not make perfect sense please feel free to ask for our site specific advice.

Old Walls

For walls that have already been painted there are two (2) options:

1. Paint over the old paint as specified above, or
2. Seal the wall with a water based gloss sealer. Flash recommend using **Cabot's Cabothane Water Based Gloss.**

Please ensure that the sealer completely covers the entire area that the SAV will be laid including the edges. Two coats must be applied and 12 hrs dry time is required.

Please note that the wall surface and paint finish is not Flash's responsibility and if paint is removed from the wall during installation of the SAV

due to the above guidelines not being followed then Flash will not be accountable for fixing the wall surface. Flash is happy to liaise with paint contractors at any time to ensure that we all get a great end result.

FREE CALL
1800 606 682
www.flash.com.au

Sydney
15 Chapel Street
Marrickville NSW 2204
T +61 2 8594 3555
E flash.aus@flash.com.au

Brisbane
23 Links Avenue North
Eagle Farm Qld 4009
T +61 7 3620 7600
E brisbane.qld@flash.com.au

Canberra
61 Kembla Street
Fyshwick ACT 2609
T +61 2 6280 6166
E canberra.act@flash.com.au